

assembly instructions

ReFrame® side mount feet

- 1** Insert knurled nuts into holes in feet so that the knurled section is on the outside

Tip: Ensure flat section of foot is under the ReFrame®



- 2** Arrange the inner tabs so that they run vertically



- 3** Align the inner tabs with the vertical slot in side of the ReFrame®

Tip: Use a pen or similar to raise the frame to make manoeuvring the feet into position more easily



- 4** Insert the tabs into the frame slot



- 5** Tighten knurled nuts



- 6** Finished!

